

Consignes de nettoyage

Prière d'utiliser exclusivement le set de nettoyage développé pour le four Atollspeed, comprenant :

1 spray **Atollspeed Oven Protectant** (protection four) ainsi que le spray **Atollspeed Oven Cleaner** (nettoyant four)

Une utilisation d'un autre produit de nettoyage peut endommager les joints de l'appareil (antenne du micro-ondes). Dans ce cas, l'entreprise Atollspeed GmbH se réserve le droit de retirer la garantie.

Atollspeed Oven Protectant est un produit spécialement développé pour protéger la chambre de cuisson contre la combustion de la saleté. En combinaison avec le **Atollspeed Oven Cleaner**, la saleté s'enlève aisément après utilisation

Avant la mise en service

1. Pulvérisez la chambre de cuisson froide avant le début du travail, avec le **Atollspeed Oven Protectant** répartissez le produit dans la chambre de cuisson uniformément, en couche mince à l'aide d'un chiffon doux ou d'un papier absorbant. Ce mince film protecteur est à appliquer une fois par jour avant le début du travail.
2. Ensuite enclencher le four. En chauffant le four, **l'Atollspeed Oven Protectant** „s'accroche“ à la chambre de cuisson et forme ainsi un film protecteur à l'intérieur de l'appareil. det somit einen Schutzfilm im Geräteinneren.



A T T E N T I O N :
toujours utiliser des gants et des lunettes de protection. Assurez-vous que l'appareil soit bien éteint.

Après utilisation journalière

1. Eteignez le four. Appuyez sur la touche 1 seconde.
2. Sur l'écran, l'indication „**Shutting down/ Ausschalten/Eteindre**“ apparaît. Choisissez maintenant „**Cleaning/Reinigung**“.



3. Après ce choix, le four passe en mode « écran de refroidissement ». Ouvrez à porte à 45°
4. Le four refroidit automatiquement à 50°C. Le processus de refroidissement est représenté visuellement. Après le refroidissement, un signal retentit. Maintenant le processus de nettoyage peut débuter.



5. Enlever le support de la plaque. Pulvérisez la chambre de cuisson avec le **Atollspeed Oven Cleaner** et laissez agir env. 10 à 15 min. La saleté se dissout mieux si le four est tiède.
6. Lors des salissures tenaces (spécialement lors de la combustion de reste de graisse dans la chambre de cuisson) répétez le point 5.
7. Nettoyer la chambre de cuisson avec suffisamment d'eau claire. Le produit de nettoyage doit être complètement rincé avant que l'on puisse retravailler avec le four.
8. Après le nettoyage, appuyez sur „**Completed/Fertig/Fin**“ afin de confirmer le fin du processus de nettoyage.
9. Veuillez le répéter „avant la mise en service“ (protection de la chambre de cuisson au moyen du produit **Atollspeed Oven Protectant**) à la fin de ce processus ou avant la prochaine mise en service.



Cleaning Instructions

Please only use the specially developed cleaning system from Atollspeed. This system comprises the **Atollspeed Oven Protectant** and the **Atollspeed Oven Cleaner**.

The use of other cleaning products could cause damage to parts of the oven, such as the microwave antenna. In such cases, Atollspeed GmbH reserve the right to waive liability should there be any claims on the guarantee.

Atollspeed Oven Protectant is a specially developed liquid to protect the stainless steel surfaces of the oven chamber from grease. In combination with the **Atollspeed Oven Cleaner** it makes cleaning the oven easy after use.

Daily - before using the oven

1. Spray the **Atollspeed Oven Protectant** into the cold oven and distribute it evenly with a soft cloth or some kitchen paper to form a thin film over all the surfaces. This procedure should be carried out every day before the oven is in use. (**Important:** The **Atollspeed Oven Protectant** must only be used in cold ovens!)



2. Next – start the oven. Via heating the oven, the **Atollspeed Oven Protectant** adheres to the baking chamber creating a thin protective film over all the stainless steel surfaces.



A T T E N T I O N :
Always use gloves and protective glasses when cleaning the oven and ensure that the device is switched off.

Daily cleaning

1. Switch off the oven. Keep the on/off button pressed for 1 second.



2. On the display „Shutting down“ will appear - now select „Cleaning“.

3. After selection, the oven will display the cooling down window. Now open the door to a 45° position.



4. The oven automatically cools down to 50°C. The cooling process is depicted graphically on the display. When the oven reaches 50° the oven will beep- now the oven is ready for cleaning.

5. Take out the Stone/Hot Spot and the tray holder from the baking chamber. Spray the **Atollspeed Oven Cleaner** in the baking chamber and let it work for 10- 15 minutes. The oven is easiest to clean when luke warm



6. For heavy soiling (especially with excessive burnt on food and grease residues) please repeat Pt. 5.

7. Clean the baking chamber with sufficient clear water. All cleaning fluid residue must be removed from the baking chamber before the oven is used again.

8. After cleaning, please press „Completed“ on the display to confirm cleaning is over. The oven will then switch off automatically.

9. Please repeat „Daily- before using the oven“ (Protecting the baking chamber with **Atollspeed Oven Protectant**) after cleaning or before the oven is used again – to ensure easy cleaning after the next use.