PRODUCT DATA SHEET



# C22 Cleaning tab

## Professional detergent for Electrolux Professional SkyLine Ovens

Electrolux C22 Cleaning Tabs have been especially developed for Electrolux Professional SkyLine ovens. Regular use of C22 tabs guarantee cleanliness of your equipment, ensuring product performance whilst also maintaining relevant warranty conditions.

## Applications

For Electrolux Professional ovens featuring the Electrolux Cleaning System.

## Description

C22 cleaning tabs a phosphate free, environmentally friendly, high effective detergent for thorough cleaning of greasy, oily and burnt-in soils.

- Guarantees hygiene safety for healthy food preparation
- Simple application in an easy to use dosage.
- Minimal environment impact achieved through degradable ingredients
- Alkaline level, pH (1%) > 13
- Works in combination with Electrolux C25 Rinse and Descale Tab
- ► Semi-transparent container packaging provides easy re-order indication

## Product developed and tested by Electrolux Professional.

C22 cleaning agent work in harmony with Electrolux Professional SkyLine ovens featuring the Electrolux Cleaning System. Best cleaning performance is achieved when the C22 cleaning tab is used in conjunction with the oven cleaning programme, in accordance with Electrolux user specifications.

## **Chemical-physical characteristics**

Appearance	tablet
Colour	white
Odour	characteristic
Weight	65 g
Solubility	completely soluble in water
pH (1%)	> 13

## 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14



Images shown are a representation of the product only and variations may occur.





#### PRODUCT DATA SHEET

## Instruction for use

- 1. Wear protective gloves and safety glasses when handling the product
- 2. Put the C22 Cleaning Tab into the appropriate basket of the integrated cleaning system on the bottom of the oven cavity
- 3. Enter the washing cycle program and follow the on-screen instructions

## Package:

Bucket container with 100 tabs.

Code:

0S2395

### Warnings:

- ► Intended for professional use only; do not use in household appliances
- Store in a cool and dry place
- Keep the bucket closed
- To be used within 36 months from the date of production
- Used sachets and container bucket can be recycled in accordance with current legislation and local conditions
- For further information please refer to product labelling and the safety data sheet

